

M32C Firmware Update Process

Important:
Save your show files before updating!

1. Download update zip file from www.music-group.com, unzip it, load it onto a USB stick formatted for FAT32.
2. While the unit is switched off, plug your USB stick into the USB port on the front.
3. Upon powering up, depress and hold down the rotary encoder located to the right of the screen.
4. The screen will inform you about the update progress and automatically boot once finished.