

M32 & X32 Firmware Update Process

Important:
Save your show files before updating!

1. Download update zip file from www.music-group.com, unzip it, load it onto a USB stick formatted for FAT32.
2. While the console is switched off, plug your USB stick into the USB port.
3. Upon powering up, hold down the "VIEW" button located next to the USB port.
4. The console screen will inform you about the update progress and automatically boot once finished.